

PHOTO + FIELD REPAIR ATLAS

Select the repair | connector, splice, or junction

The proper repair is determined by where the damage is and what the component manufacturer permits. Different connection styles require different terminals and tools. A marine-grade component alone does not establish suitability in an automotive circuit.

Damaged / overheated housing

Replace connector or OEM-approved pigtail; preserve terminal mapping and seal.

Serviceable screw terminal

Use maker-approved wire termination and clamping method; secure strain relief.

Cut or corroded harness wire

Replace damaged length with same or approved gauge; use specified sealed splice.

Branching / two wires at one screw

Use manufacturer-approved multi-conductor terminal or rated junction arrangement.

Unknown or unverified ground

Identify designed return and verify under load; never improvise a random bolt.

Module, ABS, twisted pair or shield

Consult vehicle/OEM service method; some circuits require specialized repairs.

Do not repair by twisting wires together and wrapping them with tape alone. Avoid unapproved tap splices, uninsulated barrels, unsupported free-hanging joints, and joining two separately controlled lamp outputs into one circuit.


PHOTO + FIELD REPAIR ATLAS

Sealed crimp splice | preparation to protection



1 PREPARE

Power off, confirm circuit ID, sound copper, matching gauge and approved barrel.



2 CRIMP

Insert fully, select maker-specified die/tool, make each required crimp; inspect.



3 SEAL

Apply sized adhesive-lined heat shrink and shielded heat until specified seal forms.



4 ROUTE

Stagger multiple splices, restore conduit, clamps and bend/abrasion protection.

Ford/Motorcraft source: Published wire-splice kits specify correct-size crimp barrels and adhesive-lined heat shrink. Always confirm the repair method permitted for the actual Ford chassis, upfit harness, circuit type, and wire gauge. The photos are conceptual training illustrations.

PHOTO + FIELD REPAIR ATLAS

The failure points | what to catch before release

01 Stray copper or wires touching terminals

Inspect every rear contact with good light; restore separation and appropriate insulation.

02 Loose screw / incorrect terminal style

Use housing/terminal-approved method and installation torque; do not crush strands.

03 Mixed wires under one unlisted terminal

Trace both endpoints, then move any branch to an approved junction/terminal.

04 Corrosion extending under insulation

Replace conductor to sound copper; inspect for wicking and moisture source.

05 No verified trailer ground return

Trace assigned ground through connector and measure return voltage loss under load.

06 Wrong adapter brake/aux mapping

Power off; map both sides before any powered paired test.

07 Splice against sharp metal or moving bed

Support, loom, grommet and separate from hot, moving or abrasive surfaces.

No part is cleared because it merely looks clean. Verify the exact repaired circuit under its expected command and load. Perform related-function checks to catch cross-feed, backfeed, brake or ground interactions.

PHOTO + FIELD REPAIR ATLAS

After the repair | prove the complete function

Record actual measurements before saying a repair is complete. These steps teach workflow; exact permissible voltage/current levels and brake tests come from the relevant manufacturer.

01**AS-LEFT PHOTO**

Connector face and rear, grounded routing, correct wire ID and restored seals.

02**TRUCK 6-WAY ALONE**

Left/right, stop, tail, auxiliary, controller, and loaded return as applicable.

03**TRUCK 7-WAY ALONE**

Repeat independently; do not copy readings or assume shared relays/ground.

04**ADAPTER ISOLATED**

Manufacturer/part ID, de-energized map, unintended cross-connection check.

05**TRAILER INDEPENDENTLY**

Matched tester; lamp functions, appropriate brake/breakaway/ABS verification.

06**PAIRING UNDER CONTROL**

Secure stationary load checks by qualified personnel; no road-based discovery.

07**REPEAT UNDER CONDITIONS**

Brake+turn, markers+turn, key states, loaded grounds, interlocks as equipped.

08**RELEASE / HOLD**

Date, measurements, operator, photo/tester IDs, exact approved pairing and adapters.

Not verified = not approved. Each modified connector or adapter requires a new baseline. Never equate one trailer test with approval for all interchangeable fleet equipment.